WWW.BARTBELLONSHOP.COM



## Follow these brief instructions to charge your Chameleon® II collar via induction:

1. PLUG IN YOUR CHARGING PLATE WITH THE LETTERS "AUKEY" ON THE TOP. PLUG THE USB END OF THE CABLE INTO A USB PORT ON A WALL PLUG AND THE OTHER END OF THE CABLE MUST BE PLUGGED IN TO THE CHARGING PLATE. WHEN THE CHARGING PLATE IS PLUGGED IN AND READY, THE LED ON THE CHARGING PLATE WILL BE WHITE.

2. PUT YOUR INDUCTION CHAMELEON® (IN SWITCHED ON OR SWITCHED OFF MODE) WITH THE BATTERY ISLAND (MARKED WITH A WHITE CIRCLE) ON TOP OF THE CHARGING PLATE. MAKE CERTAIN THAT THE CENTRE OF THE WHITE CIRCLE IS CENTRALISED ON THE CHARGING PLATE.

3. WHEN CHARGING, THE CHAMELEON® II LED ON THE BATTERY WILL BE ILLUMINATED CONTINUOUSLY IN GREEN AND THE LIGHT ON THE CHARGING PLATE WILL ALSO BE GREEN OR SOMETIMES FLASHING GREEN. THE MAIN THING IS TO LOOK AT THE CHAMELEON® LED.

4. WHEN TOTALLY CHARGED, THE GREEN CONTINUOUS LED ON THE CHAMELEON® WILL LIGHT NO MORE.

5. IF NO CONTINUOUS GREEN LED IS SEEN ON THE CHAMELEON® BATTERY ISLAND DURING CHARGING, THE CHAMELEON® DOES NOT NEED TO BE CHARGED.

LEAVING THE CHAMELEON® ON THE INDUCTION PLATE WITH A FULL CHARGE WILL NOT HARM YOUR BATTERY OR YOUR CHAMELEON® IN ANY WAY.

6. DURING THE CHARGING PROCEDURE, THE INDUCTION PLATE AND THE BATTERY ISLAND ON THE CHAMELEON® WILL FEEL WARM. THIS IS NORMAL.



**CHAMELEON®** INDUCTION CHARGER COMES WITH A PLATE AND A USB CABLE.

7. AFTER BEING FULLY CHARGED, THE CHARGE WILL LAST FOR A MINIMUM OF 24-HOURS IN STANDBY MODE. THIS TIME COULD ACTUALLY BE THREE OR FOUR DAYS AND IS AFFECTED BY AMBIENT TEMPERATURE.



If customer support is needed, please contact BCBB via email to make a FaceTime or Skype appointment. Ninety percent of all problems we can solve via video conference.

THANKS FOR PURCHASING THE MOST INNOVATIVE PRODUCT ON THE MARKET.

## THE BART BELLON SHOP

green.

EMAIL: INFO@BARTBELLONSHOP.COM WEBSITE: WWW.BARTBELLONSHOP.COM

## CHAMELEON<sup>®</sup> II INDUCTION CHARGING

The electronics in the Chameleon<sup>®</sup> are tuned by Martin System.